


HOME DECORATORS COLLECTION

Model #DHGKS7168TX

USE AND CARE GUIDE

LAMPORT WIDESPREAD LAVATORY FAUCET WITH POP-UP



Questions, problems, missing parts?
Before returning to the store, call Customer Service
8 a.m. - 6 p.m., EST, Monday - Friday

1-800-986-3460

HOMEDEPOT.COM/HOMEDECORATORS

THANK YOU

We appreciate the trust and confidence you have placed in Home Decorators Collection through the purchase of this faucet.

We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs.

Table of Contents

Table of Contents

1

Warranty

1

Limited Lifetime Warranty

1

Care and Cleaning

1

Pre-Installation

1

Planning Installation

1

Tools needed for installation.

1

Package Contents

2

Service Parts

3

Installation Preparation

4

Operation

6

Warranty

LIMITED LIFETIME WARRANTY

This product been manufactured under the highest standards of quality and workmanship. The manufacturer warrants to the original consumer purchaser that this faucet will be leak and drip free during normal domestic use for as long as you own it. If this faucet should ever develop a leak or drip during this time, the manufacturer will, free of charge, provide the parts necessary to put the faucet back in good working condition. The manufacturer warrants to the original consumer purchaser, for the spray to be free from defects in material and workmanship for one (1) year from date of purchase. A replacement for any defective part will be supplied free of charge for installation by the consumer. Defects or damage caused by the use of other than genuine parts are not covered by this warranty. This warranty shall be effective from the date of purchase as shown on the purchaser's receipt. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. This warranty is valid for the original consumer purchaser only and excludes industrial, commercial, or business use of the product, product damage due to installation error, product abuse, or product misuse, whether performed by a contractor, service company, or yourself. The manufacturer will not be responsible for labor charges and /or damage incurred in installation, repair or replacement, not for incidental or consequential damages, so the above limitation or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which may vary from state, province to province, and nation to nation. The manufacturer will advise you of the procedure to follow in making warranty claims.

Contact the Customer Service Team at 1-800-986-3460 or visit www.HomeDepot.com/Homedecorators

Care and Cleaning

- ☐

Never use harsh abrasives or cleaners with alcohol or acids to clean the faucet.
- ☐


To clean, use a soft, damp cloth and warm soap and water and dry with a soft towel.

Pre-Installation

PLANNING INSTALLATION


Before you begin to install this product, ensure that all parts are present. Compare parts with the package contents list. If any part is missing or damaged, do not attempt to install the product. Contact customer service for replacement parts.

TOOLS NEEDED FOR INSTALLATION



Pre-Installation (continued)


PACKAGE CONTENTS



Part	Description	Quantity
A	Cold Valve	1
B	Hose	2
C	Cone Washer & Coupling Nut	2
D	Spout Body	1
E	Aerator	1
F	Hot Valve	1
G	Pop-Up Rod	1
H	Brass Pop-Up	1
I	Allen Wrench	1

Service Parts

MODEL TYPES: DHGKS7168TX



Part	Description
1	Aerator
2	Spout
3	Washer
4	Washer
5	Stainless Steel Washer
6	Steel Washer
7	Brass Nut
8	Washer
9	Brass Tee
10	Cone Washer
11	Stainless Steel Washer

Part	Description
12	Brass Nut
13	Cold Handle
14	Escutcheon
15	Washer
16	Steel Washer
17	Brass Locknut
18	Cold Cartridge
19	Valve
20	Hose
21	Cone Washer
22	Coupling Nut


Part	Description
23	Hot Handle
24	Hot Cartridge
25	Pop-Up Rod
26	Screw
27	Clip
28	Link
29	Brass Nut
30	Washer
31	Rod
32	Washer
33	Body

Part	Description
34	Tailpiece
35	Brass Nut
36	Washer
37	Seal
38	Washer
39	Trim Ring
40	Stopper
41	Allen Wrench(3mm)

Installation Preparation


1

- ❑ Shut off hot and cold water supply under sink.
- ❑ Plug sink drain with cloth to avoid losing small parts.
- ❑ If replacing an old faucet remove the old faucet and drain assembly. Clean any old caulking or putty from the mounting holes and drain opening in the sink. Inspect the drainage slip joint nuts and washers (not included with faucet) on drain connection for damage and replace if required.




2

- ❑ Install new faucet shank through the center hole of sink.
- ❑ Place mounting washer on spout shank and attach with spout shank locknut.




3

- ❑ Apply Teflon tape to threads on spout shank.
- ❑ Attach spout tee on the spout shank



4


- ❑ Hold the handles in proper position.
- ❑ Make sure that the top of the faucet handle is 5/8" above the top of the sink. Mount the metal washer and locknut from underneath the sink.
- ❑ Then reposition escutcheons as necessary to a desired height.
- ❑ Attach the handle to the base and evenly tighten the set screws with the provided Allen Wrench.



Installation Preparation


5

- Apply Teflon tape to all male threads.
- Connect the flexible tubes from the supply shank side port to the spout tee.
- Attach the supply lines.




6

- Apply Teflon tape to inlet shanks and connect supply lines.




7

- Thread mounting nut and bottom gasket onto drain body.
- Wrap top threaded end of the drain body with Teflon tape.



8


- Apply silicone to bottom side of flange.
- Install flange body up through the drain opening, hold the drain flange body in position with pivot rod opening facing the back of sink and hand tighten mounting nut.
- Be sure to clean excess silicone.



Installation Preparation


9

- Place pivot rod into pivot rod opening.
- Slide pivot nut over pivot rod and thread it on the drain body.
- Tighten firmly.




10

- With lift rod in position on the faucet, insert lift rod through lift rod strap and secure with the clevis screw.
- Guide the pivot rod through one of the holes on the lift rod strap and secure it with the spring clip.
- Then adjust the height of the lift rod by resetting the clevis screw.



11


- Turn on water supply valves and check for leaks, especially all supply line connections.



Operation

1

- Remove aerator and turn on both hot and cold valves, let water run for at least one minute, this will clear any debris left in the line, reinstall aerator.



HOME DECORATORS COLLECTION

Questions, problems, missing parts?
Before returning to the store, call Customer Service
8 a.m. - 6 p.m., EST, Monday - Friday

1-800-986-3460

[HOMEDEPOT.COM/HOMEDECORATORS](https://www.homedepot.com/homedecorators)

Retain this manual for future use.